

# **Technical Specification**

Model: HK-LF-312-20, HK-LF-540-14

Name: 6.6KW On-board Charger

Version: V1.0

**Issue Date: 2021.1** 

Content	
1 Overview	4
1.1 Subject	4
1.2 Main features	4
2 Charger technical specification	4
2.1 Environmental requireme	4
2.2 Charger regulatory requirements and reference standards	5
3 Charger safety regulations	6
4 Charger electrical performance	6
4.1 Input Performance	6
4.2 Output Performance	6
4.3 Low voltage output performance	7
4.4 Control Interface	7
4.5 Other	7
5 Protection functions	8
6 Function Block Diagram	8
7 Control Interface	8
7.1 Low voltage connector and pins definition	9
7.1.1 Connector pins definition	9
7.2 High voltage connector and pins definition	10
7.2.1 AC input connector	10
7.2.2 DC output connector Input connector	10
8 Software Requirement	11
9 Mechanical Requirements	11
9.1 Size and weight	11
9.2 Appearance	11
9.3 Appearance Requirements	11
10 Installation Size	12
11 Installation Requirement	12
12 Nameplate, Package, Transport and Storage	13
12.1 Nameplate	13
12.2 Package	13
12.3 Transportation	13
12.4 Storage	14
12.5 Safe Guide	14

### 1. Overview

#### 1.1 Subject

HK-LF full-sealed on-board OBC is a product specially designed for new energy vehicle

according to China standard QC/T895-2011 Conductive On-board Charger for Electric Vehicle, which function is as the battery charger of new energy vehicle This product not only have the advantages of high efficiency, small size, high stability, long-lifetime but also have the performance of high protection level, high reliability, more protection functions, it is a ideal power supply solution for electrical vehicle. Thermal sensor is built-in the charger, has the function of over-temperature and can auto-recovery when temperature decreased. With the process of full-sealing, achieve the protection level of IP67, which make sure the excellent working under the complicated operation condition.

#### **1.2 Main Features**

- 1.2.1 Support UDS diagnosis, with CAN wake-up function
- 1.2.2 Full-sealed process, can reliably work in the temperature of -40°C~60°C
- 1.2.3 Built-in thermal sensor, shut off when temperature up to 90°C
- 1.2.4 Protection level with IP67

### 2. Charger Technical Specification

#### 2.1 Environmental Specification

▲ Working environmental temperature

Area	Lowest Temperature	Highest Temperature
Global	-40°C	60°C

▲ Storage environmental temperature

Area	Lowest Temperature	Highest Temperature
Global	-40°C	105°C

▲ Humidity: relative humidity 5%~95%, no condensation

▲ Altitude: ≤5000m

▲ Working noisy: max when working  $\leq 65$  dB, meet China standard QTC 895-2011

### 2.2 Charger regulatory requirements and reference standards

The design and manufacture of this product must meet the related requirements of vehicle which applicable regulations and standards in China, reference standards as following:

No.	Standard Code	Standard Name	
1	QC/T 895-2011	Conductive on-board charger of electrical vehicle	/
2	GB/T 30512-2014	Prohibited substances requirement	/
3	GB/T 18387-2008	Limits and measurement methods for electromagnetic field emission intensity of electric vehicles, broadband, 9kHz~30MHz	/
4	GB/T 18384-2015	Safety requirements of electrical vehicle	
5	GB/T 18487-2015	Electric vehicle conductive charging system	
6	GB/T 28382-2012	Technical specifications for all-electric passenger vehicles	
7	GB/T 14023-2011Limits and methods of measurement for radio disturbance characteristics of vehicles, ships and installations driven by internal combustion engines		/
23	GB/TEMC technical requirements for electronic components and subsystems of passenger vehicles		/
24	GB/T 18655-2010	Limits and measurement methods for the radio disturbance characteristics of vehicles, ships and internal combustion engines used to protect vehicle-mounted receivers	/

# 3. Charger Safety Regulations Specification

	Condition	Requirement
Grounding resistance test	@25A/AC	≤100mΩ
Input insulation test	@1000V/DC	≥20MΩ
Output insulation test	@1000V/DC	≥20MΩ
Input withstand test @2000V/AC 1min Leak current≤15ma		Leak current≤15ma
Output withstand test	@2000V/AC 1min	Leak current≤10ma
Input to Output withstand test	@2000V/AC 1min	Leak current≤10ma

# 4. Charger Electrical Performance

# 4.1 Input

	Input voltage range	AC 90~265V
	Frequency	47~63Hz
	Input Current	≤32A
Input	Power Factor	≥0.98 @≥1650W
	Efficiency	≥93% full loading
	Stand-by power consumption	≤5W
	Starting inrush current	<u>≤</u> 48A

# 4.2 Output

	Nominal Voltage Platform	540V	312V
	Output voltage range	400-680V	200-450V
	Max output current	14A	20A
	Output power	6600W@220VAC; 3300V	W@110VAC
	Output way	CV/CC	
	Efficiency	≥94%	
	CV accuracy	±1%	
Output	CC accuracy	±2%	
	Ripple voltage coefficient	±5%	
	Output voltage rising time	<5S, overshoot<10%	
	Shut off response time	Current decreased below 10% in 300ms, and decreased 0A in 500ms	

# 4.3 Low Voltage Output

	Output way	CV
	Output voltage	12V
Low	Nominal current	5.5A
voltage Output	CV accuracy	$\pm 2\%$
	Output Power	≤66W
	Ripple voltage coefficient	≤1%

### 4.4 Control Interface

12V wake-up input	≤10mA
12V wake-up signal output Max 0.2A	
12V CV	Sleep current≤1mA, peak current≤5A
CAN Communication	yes
Baud rate	Optional for 125Kbps、250Kbps、500Kbps
Terminal resistance	Not available

### 4.5 Other

EMI	Meet GB/T 18487.3-2001 11.3.1 and GB/T 18655-2018	
EMD	Meet GB/T 18487.3-2001 11.3.2 and GB/T 18655-2018	
Harmonic current	Meet GB 17625.1-2003 6.7.1.1	
Protection level	IP67	
Vibration resistance	10~25Hz swing 1.2mm, 25-500Hz 30m/S <sup>2</sup> , 8hours each direction	
Noisy	$\leq 65 dB$ (Class A)	
MTBF	150000Н	

# 5. Charger Protection Functions

	Input over-voltage protection	AC270±5V
	Input low-voltage protection	AC85±5V
	Output over-voltage protection	Stop output when exceed the highest voltage $\pm 5V$
	Output low-voltage protection	Stop output when below the lowest voltage $\pm 5V$
Protectio n	Over-temperature protection shut off when rise to 90	Power start to decrease when internal temperature rise to 85°C, shut off when rise to 90°C
unctions Output short circuit protection	Stop output	
	Output polarity reverse protection	yes
	Grounding protection	$\leq 100 \mathrm{m}\Omega$
	CAN Communication protection	Automatically stop output when CAN communication fails
	Power-off protection	Yes

## 6. Function block diagram



### 7. Control Interface

The interfaces in the charger can be grouped into two categories, one category is low voltage interface, the

other is high voltage interface.

Low voltage interface includes control connector

High voltage interface includes AC220V input, DC output and HIVL

Connectors can be appointed by customer if quantity order is more than 5000pcs.

# 7.1 Low Voltage Connector and Pins Definition



Brand	Pin	Definition	Note
	10	12V 5A Output Positive	
	11	CAN-H	
	12	CAN-L	
Molex	13	HVIL positive	
	14	HVIL negative	
	17	GND	
	Others	NA	
Socket	348302001		
Plug	334722006		

### 7.2 High Voltage Connectors and Pins Definition

# 7.2.1 AC Input



Brand	Pin	Definition
AMPHENOL	1	零线 (N)
	2	地线 (PE)
	3	火线 (L)
	A\B	NC
Socket P/N:	HVSL633023A	
Plug P/N:	HVSL633063A106I	

# 7.2.2 OBC Output



Brand	Pin	Definition	
	1	Positive	
TE	2	Negative	
	A, B	HVIL	
Socket P/N:	2103124-5		
Plug P/N:	2103177-5		

# 8. Software requirements

## 8.1 CAN communication

No.	Items	Technical indicators	Notes
1	Baud rate	250Kbit/s OR 500 Kbit/s	/
2	CAN bus communication protocol	Comply with CAN2.0B specification	/
3	Terminating resistor	No terminating resistor	/

### 9. Mechanical requirements

#### 9.1 Size and weight

	Length (mm)	Width (mm)	Height (mm)	GW (KG)
Fan-cooled	302±5	270±2	115.5±3	$\leq 8$

#### 9.2 Appearance



Fan-cooled

#### 9.3 Appearance requirements

The surface of the part should be smooth, free from defects such as delamination, rust, cracks, spots, burrs, deformation, and hand-accessible bumps. The connecting parts are complete, the parts are securely fastened, and there are no defects and damages such as rust, burrs and cracks. The connector sheath and pins should be intact and free of damage, and the components must be fastened.

### 10. Installation size



### 11. Installation requirements



Best way to install

(At least 50mm distance off to any obstacle)



Forbidden way to install



Acceptable way to install

# 12. Nameplate, Package, Transport and Storage

### 12.1 Nameplate

Require information in the nameplate shall be traceable

The basic parameters of the nameplate include: model, rated voltage, rated power, production date, serial number, etc.

#### 12.2 Package

The packing box shall be provided with product name, model, manufacturer identification, inspection certificate of the manufacturer's quality department, manufacturing date, etc; There is a list of accessories in the packing box:

No.	Item	Qty	Unit	Remark
1	On-board Charger	1	pc	
2	Outboard bill	1	pc	

#### 12.3 Transportation

The product shall be transported in a firm packing box, which shall comply with the provisions of relevant national standards and shall be marked with "handle with care" and "moisture-proof". The packaging box containing the product can be transported by various means of transportation. Direct rain and snow and mechanical impact shall be avoided during transportation.



#### 12.4 Storage

The products shall be stored in the packing box when not in use. The ambient temperature of the warehouse shall be -10-40 °C and the relative humidity shall not be greater than 80%. There shall be no harmful gas, flammable, explosive products and corrosive chemicals in the warehouse, and there shall be no strong mechanical vibration, impact and strong magnetic field. The packing box shall be at least 20cm above the ground and at least 50cm away from the wall, heat source, window or air inlet, The storage period under the specified conditions is generally 2 years, and the inspection shall be carried out again after more than 2 years.

The product shall be stored in a ventilated and dry place. At the same time, high temperature sources, fire sources and chemicals must be avoided. Store neatly to avoid throwing.

#### 12.5 Safe Guide

Warning: remind the user that the operation is dangerous

- \* It is strictly prohibited to disassemble and refit the on-board charger for repair or commissioning
- \* Do not place the parts in the rain
- \* Please confirm that the housing is intact before installation. If it is damaged, please replace it immediately

or contact the after-sales service department

\* All plugs and sockets shall be connected firmly. If they are damaged or loose, please replace them immediately

\*It is strictly prohibited to plug and unplug the connector when the product is powered on, otherwise personal injury may be caused

\*It is strictly prohibited to open the product shell during the power on operation of the product, otherwise personal injury may be caused

\* It is strictly forbidden to touch the high-voltage live parts of the product with bare hands. Please wear insulating gloves, insulating shoes Insulating clothing, live maintenance and detection are strictly prohibited

\*During the replacement of fuses and contactors, barbaric operation is strictly prohibited to avoid damaging the product and causing potential safety hazards

\* Three core cable with grounding wire shall be selected for AC power supply, and the grounding wire

\* Please unplug the power plug if there is abnormal sound or smell during the operation of the charger

\* Please keep away from fire sources and inflammables and explosives when the battery is normally charged

\* Do not charge damaged or non rechargeable batteries

#### Note: remind the user that the following operations are important operations of the product

\* Do not block the air inlet and outlet of the charger to prevent overheating

\* Please make sure that the output cable is not too long to avoid the impact of line voltage drop on charging

\* Please disconnect the power cord and charging plug when moving the charger

\* The battery voltage must be consistent with the nominal voltage of the charger

\* Avoid collision, compression, pulling, twisting or shaking the charging cable

\* The product should be placed in a safe, ventilated, dust-free and rain free environment

\* Please pack and store if not used for a long time